



# STD-SOE Hardware Manual Version 1.0 February/2017

Beam Diagnostics Group (DIG)
Brazilian Synchrotron Light Laboratory (LNLS)
Brazilian Center for Research in Energy and Materials (CNPEM)

### About this manual

This manual is intended for people who need information about the STD-SOE hardware. Information about the timing system structure and operation, firmware, or software can be found in the corresponding manuals.

#### Contents

| 1 | Hardware Specification     | 2 |
|---|----------------------------|---|
| 2 | STD-SOE Hardware Functions | 3 |

## 1 Hardware Specification

STD-SOE is a 19 inches 1U module.  $110/220\mathrm{V}$  50/60Hz AC power supply.

Figure 1: STD-SOE



Table 1: STD-SOE front panel connectors

| Connector   | Type           | Description / Specification       |
|-------------|----------------|-----------------------------------|
| OUT1 - OUT4 | BNC            | Outputs (5.0V TTL level)          |
| IN1 - IN4   | HFBR-4531/4532 | Optical Input (Agilent HFBR-2528) |

Table 2: STD-SOE front panel leds

| LED      | Type       | Description / Specification |
|----------|------------|-----------------------------|
| PWR      | Green LED  | Power on                    |
| TRIGGER1 | Yellow LED | (On) Uplink established     |
|          |            | (Blink) Trigger output      |
| TRIGGER2 | Yellow LED | (On) Uplink established     |
|          |            | (Blink) Trigger output      |
| TRIGGER3 | Yellow LED | (On) Uplink established     |
| THIGGERS |            | (Blink) Trigger output      |
| TRIGGER4 | Yellow LED | (On) Uplink established     |
| INIGGEN4 |            | (Blink) Trigger output      |
| ITL1     | Red LED    | Interlock input activated   |
| ITL2     | Red LED    | Interlock input activated   |
| ITL3     | Red LED    | Interlock input activated   |
| ITL4     | Red LED    | Interlock input activated   |

Table 3: STD-SOE rear panel connectors

| Connector | Type   | Description / Specification |
|-----------|--------|-----------------------------|
| ITL_IN_1  | BNC    | Interlock input 1           |
| ITL_IN_2  | BNC    | Interlock input 2           |
| ITL_IN_3  | BNC    | Interlock input 3           |
| ITL_IN_4  | BNC    | Interlock input 4           |
| BYPASS    | Switch | Bypass interlock input      |

#### 2 STD-SOE Hardware Functions

The STD-SOE module is an Optical to Electrical converter used for converting Timing System triggers. The module has 4 Plastic Optical Fiber inputs (IN1 - IN4) in the front panel. The input signals are converted to 5V TTL level electrical signals, which are output in the corresponding BNC connectors (OUT1 - OUT4). The STD-SOE has 4 independent interlock inputs in the rear panel (ITL\_IN\_1 - ITL\_IN\_4) related to the front panel outputs (OUT1 - OUT4). In order to bypass the interlock inputs, the BYPASS switch (rear panel) can be used.